

**UNO-3000 Series
Mounting Accessories**

User Manual

Copyright

The documentation and the software included with this product are copyrighted 2007 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation. Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp. All other product names or trademarks are properties of their respective owners.

Part No. 2003001800

1st Edition

Printed in Taiwan

January 2007

CHAPTER 1

Mounting Accessories

This chapter introduces setup UNO-3000 Series mounting accessories

Sections include:

- UNO-PM70-AE
- UNO-SM70-AE
- UNO-WM72/ 74-AE

Chapter 1 Mounting Accessories

1.1 Panel Mounting

1.1.1 UNO-PM70-AE

UNO-PM70-AE is used for Panel-Mounting with the UNO-3000 Series.

Packing List

- Panel Mount Bracket--- x2
- M4* 10 Screw--- x4

To mount the chassis to a rack, use the two panel mounting brackets in the accessory package on the front side of the chassis. These brackets can also be used for wallmounting.



Figure 1.1: Panel Mount Bracket of UNO-3000 Series



Figure 1.2: Panel Mount Bracket for Wallmounting

1.1.2 Mounting Caution



Figure 1.3: Improper Installation (1)



Figure 1.4: Improper Installation (2)



Figure 1.5: Correct Installation

Note: *Because the heat transfer mechanism is designed close to the right side of system, make sure not to attach the right side of the UNO chassis to the wall or ground (shown in Figure 3.10 and 3.11). It may cause the system to hang. Instead, try to allow some space on the right side of UNO chassis. (Figure 3.12).*

Note: *The UNO-3000 series is fanless and depends on the heat sink to transfer heat. The procedure for installing the heat-sink on the mainboard is complex, so don't try to move the mainboard from the chassis and back-plane.*

(If you uninstall the mainboard and cannot install it correctly back to chassis, the system may not be able transfer heat and will crash)

Note *Please do not sperate the mainboard (illustrated by the red circle below) from the chassis*



1.2 Stand Mounting

1.2.1 UNO-SM70-AE

UNO-SM70-AE is used for Stand Mounting the UNO-3000 Series

Packing List

- Stand Mount Bracket--- x2
- M4* 10 screw--- x4

To stand the chassis on a desk, use the two stand mounting brackets on the both side of the chassis..



Figure 1.6: Stand Mounting the UNO-3000 Series

1.3 Wallmounting

1.3.1 UNO-WM72/ 74-AE

UNO-WM72/ 74-AE is used for Wallmounting the UNO-3000 Series.

Packing List

- Wallmount Bracket--- x1
- Hook Bracket--- x2
- M3* 5 screw--- x6

1. Attach the two hooks in the accessory package to the chassis with three screws.



Figure 1.7: Attach the Two Hooks to the Chassis

2. Use the two hooks to mount the chassis on the wallmounting bracket. You can also use screws on the side to firmly attach the chassis to the wall-mounting bracket. Make sure the wallmounting bracket is in the right direction. The arrow should point upwards.



Figure 1.8: UNO-3000 Series Wallmount Bracket

3. Mount the bracket to the wall.

