PER-C30F

Quick Installation Guide



Part No. 2007C30F12 Printed in Taiwan Apr. 2007

Content

| A Message to the Customer | . 4 |
|--|-----|
| Product Warranty | . 5 |
| Ordering Information | . 7 |
| Packing List | . 7 |
| 1.1 Features | . 8 |
| 1.2 Specifications | . 8 |
| 1.3 Mechanical Drawing and Connector Locations | . 9 |
| 1.4 PER-C30F Connector List | 11 |
| 1.5 PER-T010 Daughter Board Connector List | 13 |

Notice

This guide is designed for experienced users to setup the system in the shortest time.

Safety Precautions

Warning!



Always completely disconnect the power cord from your board whenever you are working on it. Do not make connections while the power is on, because a sudden rush of power can damage sensitive electronic components.

Caution!



Always ground yourself to remove any static charge before touching the board. Modern electronic devices are very sensitive to static electric charges. Use a grounding wrist strap at all times. Place all electronic components on a static-dissipative surface or in a static-shielded bag when they are not in the chassis

A Message to the Customer

Fist of all, thank you for purchasing PER-C30F Mini PCI module. This Quick Installation Guide will help you on the process of the installation. Please read it thoroughly before you start to install it. The product comes with a two year limited warranty except for improper use. Therefore, we strongly suggest that you read and refer to the Quick Installation Guide before any installation. You may visit AAEON website for the latest version of the instruction guide. Please refer to Http://www.aaeon.com

Product Warranty

AAEON Customer Services

All products in AAEON are designed according to the strictest specifications to ensure that these products will retain reliable performance in typical industrial environments. Whether your purchase from AAEON is made for use in the laboratory or the factory facility, you can be assured that every purchase in AAEON will provide reliability and stability of operation.

Your satisfaction is our primary concern. Here is a guide for AAEON's customer services. To ensure you get full benefits of our services, please follow the instructions below step by step.

Technical Support

We want you to get the maximum performance from your products. If you run into technical difficulties, we will always be here for you. For the most frequently asked questions, you can easily find solutions in your product documentation. The guide is specific in detail so please refer to it first. Therefore, we suggest strongly that you can read it before asking for customer service over the phone. If you still cannot find the answer, gather all questions you can think of and have the product at hand before giving a call to your dealer. All dealers of AAEON are well-trained and ready to provide you as much supports as they can. Based on the customer service problems we have encountered, most of them are minor and able to be easily solved

over the phone. In addition, free technical support is available from AAEON engineers during office hours. We are always pleased to give advice regarding any installation and operation for AAEON products.

Ordering Information

PER-C30F-A10

Mini PCI 3-Port IEEE1394a Module

Packing List

- PER-C30F
- PER-T010 daughter board
- Quick Installation Guide

PER-C30F


1.1 Features

- Supports three IEEE1394a ports up to 400Mbps
- TI single chip for IEEE1394a solution


1.2 Specifications

| Form factor Mini PCI Typ |
|---|
|---|

1.3 Mechanical Drawing and Connector Locations



For model of PER-C30F



For model of PER-T010

Mini PCI Module

1.4 PER-C30F Connector List

The board has a number of connectors that allow you to configure your system to suit your application. The table below shows the function of each board's connectors:

Connectors

| Label | Function |
|-------|-----------------------------|
| CN1 | IEEE1394 Optional Connector |
| CN2 | IEEE1394 Box header |
| CN3 | Small 4P Power Connector |

IEEE1394 Optional Connectors (CN1)

| Pin | Signal | Pin | Signal |
|-----|-------------|-----|-------------|
| 1 | +12V | 2 | GND |
| 3 | TPB- | 4 | TPB+ |
| 5 | TPA- | 6 | TPA+ |
| 7 | CHASSIS_GND | 8 | CHASSIS_GND |
| 9 | CHASSIS_GND | | |

Note: When using CN1 on PER-C30F to connect any IEEE1394 device, please don't connect PER-T010 daughter board to PER-C30F. CN1 on PER-C30F and PER-T010 cannot be used simultaneously.

IEEE1394 3 ports Box Headers (CN2)

| Signal | Pin | Signal |
|--------|--|---|
| TPB1+ | 2 | TPB1- |
| +12V | 4 | +12V |
| TPA1+ | 6 | TPA1- |
| GND | 8 | GND |
| TPB2+ | 10 | TPB2- |
| +12V | 12 | +12V |
| TPA2+ | 14 | TPA2- |
| GND | 16 | GND |
| TPB3+ | 18 | TPB3- |
| +12V | 20 | +12V |
| TPA3+ | 22 | TPA3- |
| GND | 24 | GND |
| | TPB1+ +12V TPA1+ GND TPB2+ +12V TPA2+ GND TPB3+ +12V TPA3+ | TPB1+ 2 +12V 4 TPA1+ 6 GND 8 TPB2+ 10 +12V 12 TPA2+ 14 GND 16 TPB3+ 18 +12V 20 TPA3+ 22 |

Small 4P Power Connectors (CN3) – this connector is just for device power supply. It's no need to connect it when your device has its own power supply

| Pin | Signal | Pin | Signal |
|-----|--------|-----|--------|
| 1 | +12V | 2 | GND |
| 3 | GND | 4 | N.C. |

1.5 PER-T010 Daughter Board Connector List

Connectors

| Label | Function |
|-------|-------------------------------------|
| CN1 | IEEE1394 Connector |
| CN2 | IEEE1394 Connector |
| CN3 | IEEE1394 Box 3 ports header |
| CN4 | IEEE1394 Connector |
| CN5 | Small 4P Power Connector (Optional) |

IEEE1394 Connectors (CN1, CN2, CN4)

| Pin | Signal | Pin | Signal |
|-----|-------------|-----|-------------|
| 1 | +12V | 2 | GND |
| 3 | TPB- | 4 | TPB+ |
| 5 | TPA- | 6 | TPA+ |
| 7 | CHASSIS_GND | 8 | CHASSIS_GND |
| 9 | HOLE1 | 10 | HOLE2 |

Small 4P Connector (CN5)- this connector is not soldered on standard model

| Pin | Signal | Pin | Signal |
|-----|--------|-----|--------|
| 1 | +12 | 2 | GND |
| 3 | GND | 4 | N.C |

IEEE1394 BOX 3 ports HEADER (CN3)

| Pin | Signal | Pin | Signal |
|-----|--------|-----|--------|
| 1 | TPB1+ | 2 | TPB1- |
| 3 | +12V | 4 | +12V |
| 5 | TPA1+ | 6 | TPA1- |
| 7 | GND | 8 | GND |
| 9 | TPB2+ | 10 | TPB2- |
| 11 | +12V | 12 | +12V |
| 13 | TPA2+ | 14 | TPA2- |
| 15 | GND | 16 | GND |
| 17 | TPB3+ | 18 | TPB3- |
| 19 | +12V | 20 | +12V |
| 21 | TPA3+ | 22 | TPA3- |
| 23 | GND | 24 | GND |
| | | | |

Mini PCI Module

Below Table for China RoHS Requirements 产品中有毒有害物质或元素名称及含量

AAEON Main Board/ Daughter Board/ Backplane

| | 有毒有害物质或元素 | | | | | |
|--------|-----------|------|------|----------|-------|--------|
| 部件名称 | 铅 | 汞 | 镉 | 六价铬 | 多溴联苯 | 多溴二苯醚 |
| | (Pb) | (Hg) | (Cd) | (Cr(VI)) | (PBB) | (PBDE) |
| 印刷电路板 | × | | 0 | 0 | 0 | 0 |
| 及其电子组件 | ^ | 0 | 0 | | U | O |
| 外部信号 | × | | 0 | 0 | C | 0 |
| 连接器及线材 | ^ | 0 | 0 | | U | U |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

- O: 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。
- X:表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。

备注:此产品所标示之环保使用期限,系指在一般正常使用状况下。